

# INSTALLATION INSTRUCTIONS

## How to field modify a DWGV cut length (18CL and/or 30 CL)

**1** Pull apart inner and outer tubes



**2** Mark required install length  
(The formed pipe ends remain, only the raw ends are cut!)



**3** Cut inner and outer tubes to install length



**4** Debur cut edges



**5** Re-assemble inner and outer tubes



**6** Assembly complete!

